Ericsson-LG Enterprise iPECS 1010i Handset Key Features Guide



1010i Button Layout



The 1010i has 4 programmable Flex keys

Dealing with calls

received

List of phone numbers called and

Answering an Incoming Call	Lift the handset. To answer a call on another extension, press the flashing flex key and then lift the handset.
Making an External Call	Lift the handset and press a free flex key allocated to a line, or the 9 key to pick up an outside line. Once you have the outside line, dial your number.
Making an Internal Call	Lift the handset. Dial the extension number or press the flex key assigned to the contact.
Rejecting a Call	Press the DND button when a call comes in.
Call Pick Up	Lift the handset and dial 566 to pick up any handset in your group, or dial *77 and the station number to pick up a handset that's not in your group.
Placing a call on hold	Press the HOLD button. To reconnect the call, press the HOLD button again to reconnect the call.
Quick access call tools	
Speed Dial/Directory	Press the Directory button and then enter first character(s) of the name you wish to find. Press the key with the letter you require 1-4 times e.g. for the letter K press 5 twice (1 press = J, 2 = K, 3=L).
	Press OK and then use the navigation key to scroll to the entry you require. Press OK to dial the number or 'Send' from the appropriate Soft key.
Redialling a number	
Call Log	Press the LOG soft key. Scroll through the list using the Navigation buttons.

Press the LOG soft key. Scroll through the list using the Navigation buttons. To redial a number press the SEND soft key To find out information on the call press the DETAIL soft key. Press BACK to exit.

Phone Guide

Fixed Buttons

- MSG: Accesses message boxes
- Mute: Mute the call so that the caller cannot hear your voice.
- Headset (icon): If a headset is plugged in this button allows you to toggle between the
- **Dir:** Assign or use assigned station speed dial
- Trans: Transfer the current active call or access the Program menu while the phone is
- DND (Do-Not-Disturb): Blocks incoming calls. phone is ringing - this terminates the call and the caller will get a busy tone.
- Hold: Place a call on hold the caller will
- Menu button: Access the settings for your phone, such as changing the font and display or changing configuration.
- Volume button: Adjust the Ring, Headset,
- Speaker button: Toggle the speakerphone On and Off during a call. The button will automatically illuminate when the phone is in menu mode.
- Flexible buttons: A line or feature can be assigned to these buttons.
- LCD screen: Phone interface for status, dialing directories, and text message information.
- Soft Keys: These buttons are interactive and have a changing function based on the phone's

Accessing your Voicemail	Press the Message button followed by one of the following options:. 1 – to give an internal user a call back 2 – to access your missed calls 3 – to access your voicemail 4 – to access your SMS (internal message)
Listening to Voicemail (Options) Parking a call	If you do not know your password, contact your system administrator Once you have accessed your voicemail inbox here are the options available to you: Dial 1 - New messages Dial 2 - Saved messages Dial 3 - Urgent messages Dial 4 - Send messages Manage greetings Dial 5 - Personal options Dial 8 - Set greeting or password Dial 0 - To disconnect
Parking a call	To park an active external call, press Transfer , dial the park code (i.e. #601 for Park 1) Or press your assigned park key, and hang up to return to idle. To retrieve a parked call, lift the handset and dial the park code or press your assigned park key.
Camp On	When dialing an extension that is engaged, the Camp On feature allows the station to be notified that there is a call waiting. Press your assigned flex key to initiate camp on.
Transferring a call	
Transferring a Call	Press the Transfer button, dial the extension number, external number or press the programmed flex key, then either speak to the recipient to announce the call or simply hang up.
Returning to Caller from a Transfer	If you are unable to transfer the call, press the Transfer button again to return to the caller.
Features Do-Not-Disturb Makes your extension unavailable for calls	Press DND button to activate. Press DND button again to deactivate. Please note that this is not available on the attendant handset.
Ad Hoc Conference Calls 3 way calling	To call the first party, follow "Making an External/internal Call" above for instructions. Once connected press the assigned flex key Call the second party (as above). Once connected, press the assigned flex key twice to connect the calls. *To program a flex key, press Transfer then the key you wish to assign, dial 91 and then press OK .
Programming Call Forward Routes your calls to another extension/ group/speed dial - this will override your voice mail functions.	 Dial 501 (or assigned feature code) then select one of the following options: 1. Unconditional Forward (forwards all calls instantly) 2. Busy Call Forward (only forward calls when you are on the phone) 3 - No Answer Call Forward (only forwards calls if you don't answer) 4 - Busy / No Answer Call Forward (Mix of 2 & 3) Dial the extension number To disable all call forwarding, dial 502 (or assigned feature code)

DIAMOND Communications

The content of this document is subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson-LG Enterprise shall have no liability for any error or damage of any kind resulting from the use of this document

Diamond Communications (UK) Ltd Phone: 01634 290 879 Phoenix House, Desborough Park Road, High Wycombe, Buckinghamshire, HP12 3BQ